

Audio Condition Guide

Grading Overview

	Premium	A	B	C	Unacceptable
Function	100%	100%	100%	100%	<100%
Battery	≥90%	≥80%	≥80%	≥80%	<80%
Visual	Looks like new	Looks like new	Very good	Good	Visibly used/ damaged

Body

Premium	No visible signs of wear or use. Free from scratches, scuffs, dents, or any blemishes. The device’s appearance is virtually indistinguishable from a brand-new product.
A	No scratches, dents or signs of use that can be seen with the naked eye from 30 cm distance in daylight.
B	The product has minimal signs of usage, which can be visible with a naked eye from 30 cm distance.
C	The product has visible signs of usage like scratches or small dents.
Unacceptable	Deep scratches, cracks and dents. Signs of melting/burning. Device is not perfectly cleaned/dirty.

Premium Grade Device Condition

Body:

No visible signs of wear or use. Free from scratches, scuffs, dents, or any blemishes. The device's appearance is virtually indistinguishable from a brand-new product.

Pricing:

Ideally 15-20% more expensive than A grade and at least 15% cheaper than new.

Case



Earphones



Speaker



Headphones



*Please zoom in the document to see the pictured condition

A - Grade Device Condition

Body:

No scratches, dents or signs of use that can be seen with the naked eye from 30 cm distance.

Case



Earphones



Speaker



Headphones



B - Grade Device Condition

Body:

The product has minimal signs of usage, which can be visible with a naked eye from 30 cm distance.

Case




Earphones



Speaker



Headphones



C - Grade Device Condition


Body:

The product has visible signs of usage like scratches or small dents.

Case



Earphones



Speaker



Headphones



Unacceptable Device Condition


Body:

Deep scratches, cracks and dents. Signs of melting/burning. Device is not perfectly cleaned/dirty.


Case



Earphones



Speaker



Headphones

